
## ENGINE DISASSEMBLY / ASSEMBLY

## **Timing Chain Installation**


 Slowly insert the chain into chain gallery. Wiggle the chain slightly until it falls down through the engine and protrudes from the bottom of the cylinder head.

CAUTION!: Do not drop the chain into the engine.



6. Insert the stuffer end of the Timing Chain Hook / Stuffer, PN-PW-47108, tool into the chain gallery.

NOTE: The stuffer wedge will prevent the chain from catching on the sprocket.



7. Allow three to four chain links to fall past the cylinder head parting line.

NOTE: Verify the chain is not caught on the balance shaft sprocket and that the marks on the gears are still in alignment!

