## **Quick Reference Guide**

| General Information                   | 1  |
|---------------------------------------|----|
| Fuel System                           | 2  |
| Engine Top End                        | 3  |
| Engine Left Side                      | 4  |
| Engine Right Side                     | 5  |
| Engine Removal/Installation           | 6  |
| <b>Engine Bottom End/Transmission</b> | 7  |
| Wheels/Tires                          | 8  |
| Final Drive                           | 9  |
| Brakes                                | 10 |
| Suspension                            | 11 |
| Steering                              | 12 |
| Frame                                 | 13 |
| Electrical System                     | 14 |
| Appendix                              | 15 |
| Supplement-2000 Model                 | 16 |
| Supplement-2001 ~ 2002 Models         | 17 |
| Supplement-2003 ~ 2004 Models         | 18 |

This quick reference guide will assist you in locating a desired topic or procedure.

- Bend the pages back to match the black tab of the desired chapter number with the black tab on the edge at each table of contents page.
- Refer to the sectional table of contents for the exact pages to locate the specific topic required.