



ROUTINE MAINTENANCE

OPERATIONS	Operations identifications symbol	Set up	Every km/mi.				
			After the first 1000/600	1000/600	5000/3000	10000/6000	20000/12000
Engine oil level	C	●		●			
Engine oil	■ S		●		●		
Engine oil filter	■ S		●		●		
Intake engine oil filter	■ P		●			●	
Tighten engine cylinder heads	■ C		●				
Valve clearance	■ C		●		●		
Timing belts	■ C		●		●		
Timing belts change	■ S						●
Spark plugs	C/S		●		●		
Ignition advance	■ C		●				
Fuel filter	■ P/S		●		●		
Throttle body: synchronization and min.	■ C/P		●		●		
Air filter	P/S		●		●		
Engine oil pressure	■ C		●		●		
Cylinders compression	■ C		●		●		
Brake and clutch oil level	C	●	●	●			
Brake and clutch oil	■ S					●	
Brake and clutch hydr. controls	■ C	●	●	●			
Coolant level	C	●	●	●			
Coolant replacement	■ S						●
Cooling electrofan	■ C/V	●	●		●		
Motor controls	■ C/V	●					
Dashboard instruments	■ C/V	●					
Circuits sealing	■ C/V	●					
leds and lights system	■ V	●					
Head-light position	■ C	●					
Locks and hinges	■ C	●					
Battery charger for about 10 hours	■ C	●					
General clean	■ P	●					
Motorcycle test	■ C	●	●		●		
Flexible cables	C/L	●	●	●			
Tyres: consumption and pressures	C	●	●	●			
Steering bearings play	■ C	●	●			●	
Drive chain tension and alignment	C		●	●			
Final drive	■ C	●	●	●			
Brake pads wear	■ C/S		●		●		
Wheel bearings	■ C					●	
Flexible coupling	■ C		●			●	
Fuel tank	■ P					●	
Front fork oil	■ S						●
Nuts, bolts and fastener tightness	■ C	●	●			●	
General lubrication and graissage	■ L		●		●		
Battery electrolyte level	C		●	●			

OPERATIONS IDENTIFICATION SYMBOL:

- This mark indicates that the operation should be entrusted to DUCATI Service Network where high trained personnel and special equipment are available.
- C Check and/or adjustment
- L lubrication and/or graissage
- P Clean
- S Change
- V Test with running motor